


Ponta Ubu Maritime Terminal



Port Regulation



This port regulation must be delivered by the ships' agents to the shipmasters no less than 3 days prior to vessel's arrival at the Ponta Ubu Terminal.

The content of the present regulation must be thoroughly observed and followed by all masters and crews in accordance with (but not limited to): the brazilian labor law, customs, immigration, maritime and port health authorities´ rules, the international regulatory landmarks named IMO, ILO, WHO, ISO, ITF as well as the following known resolutions such as SOLAS, MARPOL, COLREG, OCIMF, and IMSBC, ISM, ISPS and BLU codes.

INDEX

1.	Port Information
1.1	Introduction
1.2	Overview
1.3	Location
1.4	Nautical Charts
1.5	Anchorage areas
1.6	Access channel
1.7	Maneuvering basin
1.8	Ponta Ubu Port Control
1.9	Address and contact details
1.10	Terminal characteristics and facilities
1.10.1	Piers
1.10.2	Ships´ characteristics
1.10.3	Tide
1.10.4	Fenders
1.10.5	Mooring equipment
1.10.6	Access ladders and extensions (planks)
1.10.7	Aids to navigation
1.10.8	Weather conditions
1.10.9	Sea conditions and local water depth
1.11	Cargo Characteristics, Origin, Handling & Stock Areas.
2.	Terminal's Rules
2.1	Vetting
2.2	Arrival and departure procedures
2.2.1	First reports
2.2.2	Maneuvering requirements
2.2.3	Tugboat Fees
2.2.4	Maximum ship's air draft
2.2.5	Loading plan, sequence and operation
2.2.6	Holds & hatch covers
2.2.7	Draft survey, draft checks, trimming & stoppages
2.2.8	Shiploader travelling / opening & closing of cargo holds
2.2.9	Delays
2.2.10	Pilotage
2.2.11	Tugboats



2.2.12	Service boat
2.3	Free Pratique, Port Health Authorities and Quarantine
2.4	Customs and Immigration (The Federal Police)
2.5	Mooring arrangements, requirements and operation
2.5.1	Vessel means of access
2.5.2	Walking on the pier
2.5.3	Persons under ship's responsibility
2.5.4	Vessel's exercises
2.5.5	Degassing
2.5.6	Firefighting
2.5.7	Emergency medical assistance
2.5.8	Deballast operation
2.6	MARPOL & potential pollution sources
2.6.1	Garbage and food waste removal
2.6.2	Bunkering
2.6.3	Air environment
2.6.4	Fumigation & Deratisation
2.7	Diving
2.8	Fishing
2.9	Repairs
2.10	Clearance of all activities before end of loading operation
2.11	Supplying of general goods, laundry services and fresh water
3.	Security (ISPS Code)
4.	Safety
4.1	Allowance for accessing ships
5.	Masters´ duties
6.	Communications & Further Information
7.	Final Requirements
8.	Annexes




PORT INFORMATION

Introduction

Although some general information of Ponta Ubu itself might be herein available, the main purpose of this item is to provide information to all parts concerned such as Agents, Owners, Charterers, Shippers, Operators, Subcontractors, Authorities, Pilots and Masters of vessels with regards to the facilities and general conditions of the Ponta Ubu Terminal, which is operated by Samarco and is not responsible for any events and errors generated by misinterpretation of the information contained herein.

1.2 Overview



INFORMAÇÕES PORTUÁRIAS

. ISPS Code . UN Locator

Code: BR POU

. Port ID nr. 27344

. ANTAQ:

. Assigned Port Facility 2711 CA 34/2014



1.3 Location

The Port is located in The District of Anchieta, Espírito Santo State Coast, about 30 nautical miles (NM) south of Vitoria City, in the following geographical coordinates: Latitude: 20°47,2' S Longitude: 040°34,4'W



A domestic airport is available in Vitoria City, which provides flights to/from Rio de Janeiro, Macaé and São Paulo.

1.4 Nautical charts

The below nautical charts covering the area are available as follows:

- . British Admiralty Chart BA 3972;
- . Brazilian Navy Nautical Charts:
- 1403 Da Ponta do Ubu ao Cabo de São Tomé
- 1404 Proximidades da Ponta do Ubu
- 22900 De Vitória ao Cabo de São Tomé




(Ponta Ubu Approaches)




Anchorage areas

The anchorage areas are authorized by the Maritime Authority. See nautical charts to know about geographical coordinates.



1.6 Access channel

The Access Channel of Ponta Ubu Port is one-way, allowing the entry or departure of one ship only at a time. It is 1.0 NM (1852m) long, 360 meters wide, 19.00 m deep (minimum depth) at the zero datum of the tide and heads to E<>W (090° <> 270°) of true direction.





1.7 Maneuvering basin

With diameter of 604m (LW) and 452m (LE) long, it allows safe turning of inbound/outbound vessels to/from the Ubu Terminal East/West berths.

1.8 Ponta Ubu Port Control

The Ponta Ubu Port Control provides a infrastructure to monitor, control, coordinate and guide all vessels within the harbor limits, utilizing the following resources:

- AIS system.
- Communications (VHF Radio Stations);
- High Resolution Surveillance Cameras;
- Environmental and Weather monitoring;

1.9 Address and contact details:

Porto de Ubu (Ubu Port)

Rod. ES 060, Km 14,4 S/N Ponta Ubu - Anchieta - ES Zip code: 29.230-000 Phone: +55

(28) 3361-9000 Fax: +55 (28) 3361-9480

E-mail: portoperation@samarco.com / isps-ubu@samarco.com

1.10 Terminal's characteristics and facilities

1.10.1 Piers

The Ponta Ubu Terminal pier is 308 m long, 22 m wide and is composed by two parallel berths known as WEST (W) and EAST (E) sides once they head to the 022° true direction.



It is also connected to the tugboats' pier (located along the East side and capable to accommodate two 28m LOA tugs alongside in line which, in turn, are able to accommodate another two tugs of the same size.



1.10.2 Ships' characteristics (by Ponta Ubu Port Resolution no. 6)

	West Berth	East Berth	Tugs Quay	General Cargo Terminal	West Maneuvering Basin	East Maneuvering Basin	Approach Channel
Draft	16.80m	13.10m	6.60m	8.10m	10,20m x 13.00m	12.40m	16.80m
LOA	301.99m	225.99m	90.99m	157.99m	301.99m	240.99m	301.99m
Breadth	52.99m	32.35m	16.99m	28.49m	52.99m	32.99m	52.99m
DWT	250,000t	150,000t	15,000 <i>t</i>	22,000t	250,000t	150,000t	250,000t
Air Draft	20.00m	20.00m	N/A	N/A	N/A	N/A	N/A
Minimum Freeboard	4.50 m	4.50 m	N/A	N/A	N/A	N/A	N/A
Remarks:	Vertical dimensions should consider astronomical tide also. Underkeel Clearance: LW 1.90m; LE and TCD 2.00m						

The operational length for both berths is 232m (between the hatch cover of hold no1 and the last one). Besides that, the maximum breadth concerning loading limitations is 52m.

Important Remark: Ships which do not match above conditions are subject to deny by Terminal's vetting criteria. All ships intending to berth at Ponta Ubu Terminal must be vetted/evaluated and approved by Samarco upon owners nomination and prior to acceptance to call the Terminal. Ships with any deck obstruction between the fore hatch covers forward of hatch cover n. 1 and the superstructure (above the hatch coamings height), shall include sketches or plans with identification of the obstructions and respective dimensions.

1.10.3 Tide

. Highest: 1.7 meters . Lowest: - 0.1 meters

. Variation: up to 1.8 meters




1.10.4 Fenders

WEST and EAST berths are fitted with fenders alongside.



1.10.5 Mooring equipment

Berths lashing points as shown below.





1.10.6 Access ladders and extensions (planks)

Access to vessels shall be through accommodation ladders, with the use of extensions (auxiliary plank) once the stand-off defense panel is about 3 m from the pier lateral edge. All accesses shall be provided with safety net as appropriate.



1.10.7 Aids to navigation

Ponta Ubu Nautical Signaling comprises 10 articulated semi-submersible buoys, 2 lighthouses, 1 lightpipe and minor lights to guide all ships in transit through the Access Channel and Maneuvering Basin till the LW, LE and TCD berths. Their details are shown in nautical chart and Sailing Directions:

1.10.8 Weather conditions

The predominant wind direction is from NE, with a frequency of 75 %.



1.10.9 Sea conditions and local water depth

The low and flat coast relief allows the wind changes direction quickly leading to formation of swells with a certain frequency. Depth increases eastwards under a soft sea bed gradient varying from 12 to 19 meters. Predominant winds of moderate intensity range from northeast to south directions along the year. The waves have significant influence on ships sailing at the Access Channel specially if associated to surface currents usually influenced by the prevailing winds. Tides may vary from minus 0.10 to 1.70 meters depending on the moon phase as usual.

1.11 CARGO CHARACTERISTICS, ORIGIN, HANDLING & STOCK AREAS

The cargo handled at the Ponta Ubu Terminal is the iron ore which is extracted from the Mine placed in Germano (Minas Gerais State) and transported as iron ore pulp (mixed with water) throughout a 400 km (249 miles) long pipeline system.

Upon arrival at the Port, this iron ore pulp passes through a filtration system (for water elimination), then enters the pelletizing process and is finally carried by a conveyor belt (passing through a sampling system) to be stacked on the stockyard.

The terminal nominal average loading rate is 12,500 t/h. Loading rates (pour) declared as port uses and practices vary according to ship's size and follow the loading rates table attached. Masters should declare to the terminal their awareness about terminal particulars and rules.

The static capacity of stockyard is 1,800,000 MT (one million eight hundred thousand metric tons). The iron ore is reclaimed from stockyard through a reclaimer which feeds the conveyor belts system (with their respective transfer chute) till the loading pier where the shiploader with its own conveyor belt and boom can properly load the ship by pouring the cargo into her cargo holds following the good practice and the operational procedure required as per the BLU Code.



2. TERMINAL'S RULES

2.1 Ship Vetting

Ship Vetting involves sourcing data on ships and evaluating the potential risks such as the ship's structural integrity, competence of owners, managers and crew, past casualties and incidents. All vessels are subject to Samarco Vetting during nomination procedure.

Vetting - Information Sources			
RIGHTSHIP	https://site.rightship.com/		
equasis	http://www.equasis.org/EquasisWeb/public/HomePage		
USCG Maritime Information Exchange Port State Information Exchange	https://cgmix.uscg.mil/psix/		
Portos e Costas MARINHA DO BRASIL - AUTORIDADE MARÍTIMA BRASILEIRA	https://www.marinha.mil.br/dpc/vistoria-de-condicao		
TOKYO MOU	http://www.tokyo-mou.org/		
Paris MoU on Port State Control	https://www.parismou.org/		
SAMARCO APRENDER PARA EVOLUIR E TRANSFORMAR	Port operational files		



2.2 Arrival and departure procedures

2.2.1 First reports

Vessels are required to report daily updated ETA to Agents who will pass on to Port Administration as follows:

Vessels are required to establish communication with Ubu Port Control via VHF channel 16 as soon as possible to update arrival time and receive berthing instructions;

The entry and departure of vessels are subject to Ubu Port Control clearance;

All ships shall report to the Ubu Port Control the following information: Agents contact details, official arrival time/position (Notice of Readiness), arrival drafts, time/position of first anchoring (as applicable) and occasional changes, anchor aweigh time, time crossing first pair of buoys, time and description of first line ashore, berthing and unberthing times, Pilot away time, occasional anchoring details (as applicable/necessary) after sailing maneuver and finally the official port departure details;

The Ubu Port Control will monitor and guide all ships anchored, underway or berthed at all times.

2.2.2 Maneuvering requirements

In the Access Channel, all inbound/outbound ships are required to observe and follow the contents of the COLREG – PART B – STEERING AND SAILING RULES – Rule 6 (Safe Speed);

All ships must have support of tugboats (with or without lines as necessary) whenever crossing out the Maneuvering Basin either way; however she must always be under her own engines as main propulsion;

Unless otherwise provided, special rules for initial maneuvers as below described are to be applied as per Port Manager decision for each inbound/outbound vessel as follows:

- . Maximum sailing draft: 16.80 meters (plus tide);
- . Wind speed up to 20 knots;
- . Use of 02-to-05 ASD tugboats of 40 ton Bollard Pull due to ship's DWT and draft;
- . Use of 01 ASD tugboat of 40 ton BP in stand by for emergency as far as the vessel remains alongside;



2.2.3 Tugboat Fees on Ponta Ubu Terminal

TUGBOAT FEES ON PONTA UBU TERMINAL			
DWT	USD		
BELOW 30,000	13,871.47		
60,001 - 90,000	30,684.00		
90,001 - 120,000	49,593.98		
120,001 - 180,000	60,109.72		
ABOVE 180,000	60,109.72		
	31-Oct-2020		

Lumpsum amounts expressed in US dollars for a mooring and unmooring with any number of employed tugs. Towing activities of vessels in extraordinary situations should be agreed in advance and transcend the objectives of this table.

2.2.4 Maximum ship's air draft

. Both berths (East and West) = 20.00 m

2.2.5 Loading plan, sequence and operation

Ships shall send Samarco their Cargo Plan Form (Annex 7) filled for port team analysis, at least 7 consecutive days before their ETA at Ponta Ubu. The Terminal might require changes for improvement of productivity which do not affect operational safety codes. However, the capitan's approval is always necessary for any change in the cargo plan. For the sake of good order or better operational performance, the Terminal might require adjustments as necessary;

In order to perform a smooth and safe watch on the vessel during load operation, Masters are required to observe and comply with the STCW rules (mainly on its Chapter VIII/2), with regards to the need of having one Deck Officer capable of discussing with the Foreman on duty, any changes on loading/sequence plans or other situation that may occur during the loading operation (BLU Code);

Unless a specific channel is established prior berthing, VHF channel 16 (156.800 MHz) shall be used for the first contact and then another channel be chosen as appropriate; however means of communication must be settled as per Ship/Shore Safety Checklist presented upon berthing;

In case of any main deck obstruction, the Terminal must be informed accordingly;



All vessels shall be suitable and capable to load according to the loading rate established by the Terminal as follows:


Nominal Loading Rate: 12,000 MT per hour;Average Loading Rate: 10,000 MT per hour;

Deballasting must be performed simultaneously to the loading operation and properly done to balance the loading rate previously settled otherwise the Foreman on duty must be immediately advised for appropriate actions as necessary;

Deballasting operation should be faster than the time planned for loading, taking into consideration the values determined as attached. Deballast operation must not be a cause for loading interruption otherwise any delays arisen from that will be for ship's account; Ship draft marks shall be in good conditions, clearly visible, and adequately illuminated, as required. The holds' numbers must be suitable painted. Cargo reserved for trimming shall not exceed 3.0 % of total load. Trimming should be completed at the end holds, or as near to the ends as possible.

Procedures considered normal and adequate for draft survey are: an initial reading prior to loading, another reading at the beginning of trimming and one upon completion of loading. No other reading shall be performed that could impair loading, except in case of unpredictable instances or ships with different loads and/or several clients.

Ships with different types of cargo shall try to obtain their loading sequence in order to finish the first one before the second cargo brand starts.



Concerning pour sequence, unless otherwise previously agreed, 2 steps per hold (normal operation) + 2 additional steps (for trimming purposes) are highly advisable;



It is not Terminal's responsibility the cleaning of the main deck and their housings, fittings, equipment, hatch coamings, hatch covers, structures, superstructures, masts or any other places of the vessel prior, during and after loading operation.

Warning: In order to avoid any loading interruption under vessel request owing to air draft restrictions, loading sequence and/or deballasting plan must be fully controlled in all respects at all times prior and during the loading operation as per the BLU Code and this Port Regulation.

2.2.6 Holds & hatch covers

Unless otherwise established by the Governing Charter Party, all cargo holds are required to be free of previous cargo, clean, dry and ready for loading, therefore Masters are required to avoid ballast water inside the floodable holds upon berthing, unless necessary for maintain the best stability of the ship.

All hatches are required to be widely opened upon berthing for visual inspection of the cargo holds except in case of moderate to heavy rains as applicable and agreed;

After cargo holds inspection and clearance given by the Foreman, unless otherwise provided, only two cargo holds are required to be kept opened at time for loading: the present and the next one. All other cargo holds are required to temporarily be kept closed until coming their turn as per the loading sequence previously settled;

In case of heavy rains, loading operation is subject to interruption as necessary and agreed. The decision to close holds shall be at the terminal discretion, unless in view of ship's safety.

2.2.7 Draft survey, draft checks, trimming & stoppages

It shall be carried out in three steps: initial draft survey, trimming and final draft survey;

Any delay or loss of time from draft checks requested by the ship besides the three steps above mentioned will be for ship's account. In this way, any stoppage under ship's request including additional draft checks regardless the reason will be definitely for ship's account;

Loading Plan shall have all trimming details which in turn shall take place just once.

2.2.8 Shiploader travelling / opening & closing of cargo holds



The shiploader can take few minutes to move itself over the various hatches; therefore it is highly advisable all persons to stay out of reach always walking on the sea side to also avoid jumping over the tensioned lines across the main deck pier side;

Any delay for opening/closing hatches will be for ship's account.

Loading operation working hours 24/7.

2.2.9 Delays due to ship's deficiencies

The Masters, Owners, Charterers, Operators, Managers and/or Ship's Agents must bear in mind that any delay to the port operations caused by the need of renewal of any ship's document/certificate or detentions imposed by The Brazilian Maritime Authority that might affect her entrance/berthing or unberthing/departure during vessel's stay in port, it will be solely for ship's account.

2.2.10 Pilotage

Pilotage is compulsory for all inbound/outbound ships through the Ponta Ubu Access Channel as per NORMAM 12 (Maritime Authority Regulation);

To safely guide and berth all ships throughout the Access Channel, unless permanently otherwise provided, Pilots are required to await them about 1 mile out of the first pair of buoys.

All pilots associated to the Espirito Santo State Pilotage for attending the Ponta Ubu Terminal are fully certified and authorized by The Brazilian Maritime Authority;

Pilotage service is available 24/7 and to be requested by ships' Agents provided minimum of 4 hours notice in advance;

Pilots will contact vessels through VHF radio channel 16 before boarding;

As per the ICS, the Pilot Boat can be recognized by its red hull and white structure and, at night time, by the vertical white and red lights on its top. In addition, unless otherwise provided, Pilots will not permit access to the Pilot Boat by anybody except themselves and the boat crewmembers.

According to the Maritime Authority Regulations, all vessels shall provide a safe pilot ladder or combination ladder (pilot ladder + accommodation ladder) as necessary and applicable, correctly and safely rigged and positioned besides to be properly illuminated during night time to improve safe conditions for pilot boarding and release;



As per NORMAM 01 - Chapter 4 – item 4.13, a life buoy provided with a heaving line no less than 30 m and a white strobe light, must be kept in sight, hung in the main deck railings close to the pilot ladder, ready to go during pilot boarding or release;

Pilotage service tariffs shall be settled between Shipowners, their Agents and Pilots Association;

For further information or more details, visit the IMPA – International Maritime Pilots Association site at http://www.impahq.org and Brazilian National Pilotage Council (CONAPRA) at http://www.conapra.org.br.

2.2.11 Tugboats

ASD tugboats (Azimuthal Stern Drive) with minimum of 40-tons BP must be regularly used for all kinds of maneuvers;

The use of tugboats is mandatory for all vessels demanding the Access Channel, Turning Basin and docking areas;

Tugboats must be requested by the ship's Agent and their service tariffs to be settled among Shipowners, their Agents and Samarco.

2.2.12 Service boat

A service boat to draft survey will be available 24/7.

2.3 Free Pratique, Port Health Authorities and Quarantine

Free Pratique shall be requested via Agents according to the Port Health Regulation (RDC 10 2012 - ANVISA). All vessels must be in Free Pratique prior berthing but even after being granted, they will always be subject to a visit/inspection by the Port Health Authorities (ANVISA) either at the anchorage or at the berth under their availability and discretion;

Quarantine Flag (yellow flag) must be kept hoisted (even during night time) until Free Pratique is granted or the ship receives clear instruction from the Port Health Authorities to lower it;

Whenever a ship is not in a satisfactory condition under the Port Health Authority judgment, Master will be required to anchor under Ponta Ubu Port Control guidance, as per Maritime and Port Healthy Authorities' Regulations. In such case, neither the cargo can be loaded nor can any crewmember be signed in/off;



Furthermore, Agents are required to send a Free Pratique scanned copy to the Port Administration as soon as it is released by the Port Health Authority.

2.4 Customs and Immigration

Ship's Agents must guide the Masters about the set of required forms to be filled in plus original documents and copies to be presented to Customs and Immigration upon berthing in order to grant clearance for the cargo to be loaded, crew, passengers, subcontractors on board, access of Terminal staff, visitors, shore subcontractors, workshops and suppliers as appropriate;

Immigration, Customs and Port Healthy Authorities might occasionally board the ship at the anchorage as necessary although the most common practice is to pay the official visit upon berthing;

Except the Pilots, no one is allowed to board or leave the ship before clearance be granted from all Authorities concerned;

In case of urgent matters at the anchorage or berths such as non-infectious disease, severe sickness, accidents, lack of foodstuff and fresh water or any other urgent matter, exceptions might be applied for appropriate support with aids of the ship's Agents under special permission by the Port and other Authorities concerned.

2.5 Mooring arrangements, requirements and operation

The Ponta Ubu Terminal will previously suggest a Mooring Plan as per drawing and prescriptions below according to studies specially developed for this matter. Once agreed, any deviation during berthing time shall be immediately discussed among Master, Pilot and Terminal representative. Once treated and carried out, any further deviation during loading operation must be reported and discussed between Master and Terminal representative;

Recommended Mooring Arrangements

Panamax vessels			
Forward station	Aft station		
2 head lines	2 stern lines		
2 breast lines	2 breast lines		
2 spring lines	2 spring lines		



Capesize vessels			
Forward station	Aft station		
4 head lines	4 stern lines		
2 breast lines	2 breast lines		
2 spring lines	2 spring lines		
	,		

Service boat is not to be used to support berthing/mooring operation;

All ship's lines must be in good condition for use as follows:

- . free of oily residues, visually not worn out or deformed and also free of fatigue evidences such as burrs, grooves, twists, kinks etc.;
- . one entire piece (without tied up pieces of broken lines);
- . eyes protected with heavy duty canvas and correctly made without improvised knot;
- . provided with a short rope (1" diameter / 1.5 m long) tied up to their eyes for easy handling;
- . provided with rat guards while vessel is moored/berthed;
- . in case of wire springs (when/if applicable), they must have no fatigue evidence and be properly greased/maintained to prevent from having heavy oxidation besides to be provided with tail not less than 11 meters according to OCIMF recommendation.

Once moored, vessels are required to keep all lines equally and properly tensioned at all times to avoid isolated line stress (overload tension) and breaking off occurrences in a row followed by spontaneous unberthing;

Should the ship need to use tugboats as an additional measure to keep her properly alongside while berthed, all costs will be for ship's account;

Mooring Arrangements as quantity, position, tension, suitability and visual/physical quality of the lines will be subject to random inspections by the Samarco personnel in order to enhance the operational condition;

While berthed, automatic tension system of mooring winches shall not be used;

Handset radios shall be used by all parts directly involved in to speed up and assure the smoothest berthing/mooring operation as possible;

Mooring execution shall be handled on board by the crew and ashore by the linesmen, always with the aid of VHF radio communications on a specific channel previously settled by the Master, Pilot, Foreman and tugboats;



BLU Code and OCIMF, as applicable, must be continuously observed while vessel remains berthed;

Personal safety equipment must always be used;

Crewmembers must always be safely positioned, well sheltered and clear against any tensioned line (specially towlines) to prevent from exposure to occasional occurrences of sudden breakup of lines;

Extra care must be paid when throwing away the heaving lines either to the tugs or to the pier. Thus, all crewmembers are strongly required to always warn the persons engaged in such activity immediately before throwing away the heaving line.

2.5.1 Vessel means of access

Crew must pay good attention to the mooring lines and keep them properly tensioned to refrain from vessel's longitudinal and transversal movements which might cause serious damages to the access ladders (gangway or accommodation ladder) and their extensions (the planks);



The access ladders and their extensions must always be provided with safety nets to prevent from having man overboard.



Regardless the ladder extension provider, The Master shall assure that his crew will pay good attention on the most probable causes for damages such as (but not limited to) shiploader movements, draft and tide variation, currents, winds, waves and/or swells that may cause the ship to move, mainly when the extension ladder is nearby the bollards along the pier;

Masters are required to guarantee a good watchkeeping (as STCW rules) for the fittings with projections beyond hull limits such as provision cranes or other devices;

Should any of the ship's lines need to be temporarily released or slacked away, Foreman on duty must be immediately contacted;

In the event of any damage to the pier fittings or Terminal's facilities be caused by a vessel regardless the Terminal's rules were observed or not, Masters will receive a "Damage Report Letter" and/or a "Letter of Protest" as applicable.

2.5.2 Walking on the pier

The crew is not allowed to walk under the shiploader on the pier. The noncompliance with this rule may cause loading interruption for safety reasons what, in such case, any time lost will be for ship's account as well as any accident and costs arisen from that.



To prevent from walking under the shiploader boom and also jumping over tensioned lines at the main deck, a safe walkway connecting the superstructure to the upper accommodation ladder platform must be provided by The Master, by any available means such as painting, balustrades, hand railings and/or zebra tapes (black and yellow color), always through the main deck sea side in order to persuade and guide all persons to walk through a safer way;



As part of the safety requirements, The Master shall guarantee that any crewmember or person under ship's responsibility who may access the pier (for draft readings or other purposes) is properly wearing "Personal Protective Equipment" such as safety helmet and shoes, goggle, ear protections, cotton gloves and lifejackets with reflexive tapes besides to always be accompanied by the Foreman on duty or person designated by him;

The shiploader will always sound an alarm about 03 seconds before moving;

The shiploader may continuously travel over its rails, stop and back to move on at any time as necessary without previous notice except the sound alarm above mentioned. Therefore it is forbidden to remain close to its crane, to step up and/or walk on its railway, whatsoever;



In case of an emergency situation, the Foreman on duty must be immediately contacted by any available means.

2.5.3 Persons under ship's responsibility

All Crew and their families/visitors, passengers and/or any other person directly or indirectly under vessel's responsibility such as (but not limited to) Agents, Shipowners Representatives, Surveyors, Subcontractors or Service Providers, Suppliers and Ship Chandlers will be permitted to temporarily board and leave the ship provided The Master makes all necessary and legal arrangements (supported and coordinated by the ship's Agents including previous communication to the Port Administration in due time), bearing in mind that all persons must wear the "Personal Protective Equipment" as above mentioned (including approved Lifejackets with reflexive tapes) whenever walking on the pier;

Regardless the citizenship, all crewmembers, passengers and extra equipage (sub-contractors, others) may sign on/off the vessel provided The Master makes all necessary and legal arrangements supported and coordinated by ship's Agents including previous communication to the Port Administration no less than 24 hours' notice in advance.

2.5.4 Vessel's exercises



Exercises such as (but not limited to) lifeboats, rescue boats, external firefighting, pollution prevention and response it shall be reported to the Terminal provided no less than 2 hours' notice in advance for authorization purposes, take place during daylight only and must never interfere or compromise loading operation, whatsoever.

2.5.5 Degassing

All ships are required to be fitted with appropriate instruments for measuring concentration of gases without requiring entry into the cargo space. These instruments shall be regularly serviced and calibrated and the crew duly trained for their correct use;

All O/O, OBO and Bulk Carrier ships engaged on carrying petroleum and its refined products or high volatility coal in the last voyage must present the following document:

A certificate stating that the atmosphere in all ship's compartments is free of flammable, toxic and inert gases (gas-free condition), presented to the Foreman on duty before commence of loading operation;

Before loading, Masters shall ensure that all cargo spaces and adjacent areas (bilge areas, cofferdams and void spaces) were checked and found clean, dry, free of previous cargoes residues and with breathable atmosphere (gas-free-for-man condition);

Regardless the previous cargoes, all ships must in every single call, present a Gas-free-forman Certificate or, alternatively, a declaration issued by Master himself, stating that the atmosphere in all cargo holds and adjacent areas is in good condition for breathing, being whatsoever, presented to the Foreman on duty before commence of loading operation;

Degassing operation or checks for the presence of flammable, toxic or inert gases must always be carried out prior berthing and never with the ship alongside, whatsoever.

2.5.6 Firefighting

The firefighting system on board must be ready for use at all times.

2.5.7 Emergency medical assistance

Should any medical assistance be required to the Terminal on emergency bases, regardless the reason, the First Aid shall take place on board and at the exact place of the occurrence instead of having the patient inadvertently removed out of ship without express authorization from the Terminal.



Warning: Failure to comply with above General Safety Precautions, the Master will be held the solely responsible and so the ship will be subject to penalties imposed by the Port Administration and/or Authorities concerned specially in the event of human injure or loss of life, time, material and/or damages related, being any delay and costs directly or indirectly involved in for ship's account.

2.5.8 Deballast operation

Vessels are required to carry out a mid ocean ballast water exchange prior arriving Brazilian Waters. The purpose of this exchange is to avoid transferring of non-indigenous microorganism species into the Ponta Ubu Port sheltered waters;

It is highly recommended to keep updated a detailed record of the water exchange as per concerned regulations in force;

It is strictly forbidden to discharge dirty ballast. Noncompliance to this rule may lead to heavy fines and penalties as per Brazilian Law with regards to the environmental protection and port operations;

Vessels must keep a close watch on deballasting performance which for any reason is observed below expectations, all delays, time lost and demurrages will be for ship's account;

Discharge of clean ballast water is allowed within Port area provided compliance with below procedures:

Masters must have full acknowledgement about the good quality of the ballast water which must be free of any kind of oil, chemicals, pathogenic organisms, bacteria and/or exotic and unwanted species;

Special attention must be paid on the ballast water management which must be in compliance with IMO Resolution A.868(20), BWM Convention/2004 (International Convention for the Control and Management of Ships' Ballast Water and Sediments), Brazilian Federal Law 9966/2000, Port Health Authority (ANVISA) Regulation RDC 217 and also with the Brazilian Maritime Authority Regulation NORMAM 20;

Ballast water cannot be discharged directly on the pier to prevent from having damages to the shiploader electrical equipment and others; for that, Masters must assure that the vessel is provided with appropriate device to avoid direct discharge from the topside tanks outlets that may cause failure and/or severe damage to the shiploader power equipment followed by loading interruption.

Warning: Vessels which do not comply with all above requirements are subject to heavy fines imposed by the Brazilian Federal Law 9605/1998.



2.6 MARPOL & potential pollution sources

Brazil is signatory of MARPOL. The Law enforces the environmental protection and special attention must be paid to Federal Law nº 9605/98 and 9966/00 which may punish with heavy fines for environmental crimes. All costs arising from any pollution caused by vessels, it will be on vessel's, Master's, Owners', Charterers', Managers', Operators' and/or their Agents' account as applicable;

Discharge of any kind of garbage (including dirty ballast water) at sea within the port limits IS NOT PERMITTED otherwise it will subject the ship to a heavy fines;

The crew must identify and manage potential sources of oil leakage located on the main deck specially from drums/cans with oily garbage, hydraulic/lubricant oil or liquid/melted grease from deck equipment, devices or fittings such as wires, oil pipelines, windlass, winch drums, gears, hydraulic jacks among others;

All oily garbage in drums, tins or cans must be properly covered and/or sheltered to avoid oily water overflow caused by rain which may reach the sea;

Sawdust bags must be always available (SOPEP) for use in the event of oil spillage or oily water produced by rain in contact with these sources;

Oily sawdust on any deck (particularly on main deck) must immediately be collected as soon as its use is done, properly packed away and kept in an appropriate place:

Main deck scuppers must always be plugged up but may be quickly released to drain clean water without any kind of trash or oil, whatsoever;

Oily water must not be allowed to overflow towards the sea. Therefore any presence of it on main deck it must immediately be pumped out to a slop tank or other appropriate compartment.

2.6.1 Garbage and food waste removal

Available by certified companies. Vessel must contact agent.

2.6.2 Bunkering

Not available.



2.6.3 Air environment

Smoking and use of naked flames are not permitted in the cargo areas and their adjacent spaces;

Soot blowing through the smokestack is not allowed during port stay;

Exhausting gases produced by ships under manoeuver must be reduced as much as possible to refrain from excess of smoke emission in the air.

2.6.4 Fumigation & Deratisation

Available by certified companies. Vessel must contact her agent.

Warning: Since all vessels are subject to Brazilian Port Health & Environmental Authorities inspections, in case of any air/water pollution be found, the ship in question will be subject to heavy fines according to Brazilian Law in force besides penalties imposed by the Port Authority.

2.7 Diving

Permitted, if necessary.

2.8 Fishing

Not allowed of any kind and under any circumstances.

2.9 Repairs

Minor repairs while in port: Any repair in progress on vessel's main deck or adjacent areas that may affect and compromise the environment, maneuverings and loading operation must be immediately ceased;

Clearance from the Terminal representative must be granted before any use of oxyacetylene gases for repairs on main deck open area and vicinities;



Regardless the kind of repair in progress on board, in case of emergency, any ship berthed at Ponta Ubu Terminal must be ready to leave within 60 minutes as from the time of request, bearing in mind the use/support of tugboats is mandatory, whatsoever.

Therefore, great routine repairs that may compromise an imminent unberthing shall not be carried out unless previously reported and duly authorized by both Maritime and Port Authorities (in this case, the Port Administration itself);

In the event of emergency repairs or great routine maintenance, even already authorized by the Maritime Authority, the Ponta Ubu Terminal reserves the right to request the ship to leave the berth and proceed to a designed anchorage area for carrying out or resume its repairs as applicable;

Furthermore, regardless the previous announced line-up, should the ship is under repair (authorized or not) at the anchorage area and not ready by the time she is called in to berth or re-berth, the Ponta Ubu Terminal reserves the right to postpone her entry and declare loss of line-up position, being all costs of delay and/or Demurrage for ship's account.

2.10 Clearance of all activities before end of loading operation

Masters must assure that any activity (as/if/when applicable but not limited to) such as general supplying (provisions, spare parts, general goods, other materials), third party services (repairs, inspections, surveys, others) and also clearance from crew changes, visitors disembarkation (and who else it may concern) must be finished no less than 2 hours prior the end of loading operation besides not to interfere with that whatsoever;

2.11 Supplying of general goods, laundry services and fresh water

General supply of spare parts, provisions and other goods shall be made under Master and Suppliers arrangements, expenses and responsibility, provided 72 hours' notice in advance to Port Administration and also duly authorized by the relevant Authorities such as Federal Police, Customs and Port Health Authorities. Fresh water available by trucks, for small quantities only.

Non-authorized vehicles, boats and pedestrians are not allowed to access or transit along the Terminal facilities and Customs bonded area.

Warning: Failure to comply with all above requirements, Master will be held the solely responsible and so the ship will be subject to penalties imposed by the Port Administration and/or Authorities concerned specially in the event of human injure or loss of life, time, material and/or damages related, being any delay and costs directly or indirectly involved in for ship's account.



3. Security (ISPS Code)

The Ponta Ubu Terminal operates in comply with the ISPS Code.

Any request to access the Port bonded area controlled by Customs it shall be addressed to the Port Security whose contact details are found below on item COMMUNICATION & FURTHER INFORMATION.

Masters and crew are required to cooperate and inform to the Port Control any suspicious behavior around the ship (including at the anchorage area) or pier.

4. Safety

Samarco Mineração S.A. has a Fire Brigade Team equipped and trained for firefighting purposes at the Iron Ore plant and port facilities. Despite Terminal facilities are provided with fire hydrants, the Fire Brigade Team and Terminals' personnel are not trained to fight fire on board vessels and therefore they will not be liable for any damages or losses arisen directly or indirectly from that.

In the event of a fire on board while at berth, the vessel shall immediately contact Port Control and, in case of losing control during fighting, it shall prepare to cast off by rigging the points defined for emergency towing among other vessel's emergency procedures. The Vessel will be towed to an anchorage area and position designated by the Port Control in order to allow adequate firefighting as necessary. For that, while berthed, all ships are required to leave dedicated wires with eyes 2 meters from the waterline at the seaside forward and aft stations for emergency purposes.

Terminal tug has a single firefighting (FIFI) system.

Ships in "gas free" condition shall take the necessary measures for issuing and submitting the Gas free Certificate document, without which the ship cannot be moored and will not be considered ready in all respects to berth/load. Therefore, any waiting time will not count as laytime or time on demurrage.

However, if there is no inflammable cargo since the last three cargoes, vessels should only send a Master's declaration in accordance with requirements below. The statement will take in trust. See the abstract below.

Resolution A.862(20) - Code of Practice for the Safe Loading and Unloading of Bulk Carriers (SOLAS VI/7), Annex, Section 3 – Procedure between ship and shore prior to the ship's arrival.

Combinated carriers (OBO or O/O) should advise of the following additional information:

- .1 nature of the preceding three cargoes;
- .2 date and place at which the last oil cargo was discharged;
- .3 advice as to content of slop tanks and whether fully inerted and sealed; and



.4 date, place and name of authority that issued the last gas free certificate which includes pipelines and pumps*.

*Reference is also made to the International Safety Guide for Oil Tankers & Terminals (ISGOTT).

All material and/or service supply shall be made in compliance with relevant legal requirements and harbor rules, and shall cause no delays. Cargo should not handle by sea/hull or using gang way or pilot ladder.

There are many high resolution cameras around the terminal. External activities might be shot and images recorded.

4.1 Allowance for accessing ships

Access to the ship is not allowed without the Captain's (or his representative's) approval, for the ship's own safety and control. Thus, the permit shall be individual (nominal) and not transferable. The request shall be made by email (sent to autporto@samarco.com) 24 hours in advance.

5. Masters' duties

As the Masters are the solely responsible for maneuverings of their vessels, they are required to provide to the port control all relevant information and/or peculiarities about any specific restrictions, failures, malfunctions or deficiencies found (but not limited to) in the ship's structure, ballast and oil tanks, cargo holds, hatch covers, rudder, main and auxiliary engines or other relevant machinery, boilers, pumps, electrical boards, navigational aid devices, mooring lines, mooring equipment or any other items that may jeopardize the safety of navigation and/or compromise the approach, access, berthing, mooring, deballasting, loading operation, unberthing and departure of the ship. Once moored, vessels should remain in conditions considered satisfactory by the Ponta Ubu Terminal. Besides that, Masters are strongly required as follows:

When entering the port in ballast condition, to guarantee that the ship is sufficiently ballasted with the propeller fully immersed to meet Pilotage requirements and, in addition, to be satisfactorily equipped and suitable for complying with required mooring arrangements;

To ensure the ship will never enter and navigate the Access Channel without Pilot on board and that will never dismiss him inside the channel when leaving the port;

To warn his crew, passengers and any other persons on board to fully abide by Brazilian Legislation including the prevention of civil and criminal wrongdoing, specially concerning smuggling of all kinds such as fire guns and ammunition, drugs, medications, chemicals, spirits, cigarettes and tobacco. It is highly recommended that the excess of spirits, cigarettes, cigars and tobacco be declared and placed in the bonded store room on board for Authorities appraisal and legal measures as necessary while in port;



To provide safe access to the ship on required side;

In case of ships equal or over 18 years old (as from her keel laying date), to guarantee the ship will be surveyed by an authorized Classification Society (other than the one of the vessel) for the issue of a Condition Survey Report on behalf of the Brazilian Maritime Authority representing the DPC (Coastal and Ports Board of Directors) – Defense Ministry, once any ship under this condition must always carry and present to the Terminal such valid Report before getting alongside or else will be subject to NOR suspension, berthing cancellation and loss of her line-up position;

To guarantee that all ship's certificates are valid and that will not be expired within the next 48 hours after ship's departure;

To guarantee and cooperate for the most satisfactory, safe and smooth loading operation bearing in mind that vessels of any age with low performance or found in substandard condition are subject to be inserted in a Low Performance Vessels List for future reference and nomination, according vetting criteria.

6. COMMUNICATIONS & FURTHER INFORMATION

Port Administration

Telephone: + 55 28 3361-9248 (working hours)

Mobile phone: + 55 28 99275-4749

E-mail: portoperation@samarco.com

Port Security

Telephone: + 55 28 3361-9248

Mobile phone: + 55 28 99275-4219

E-mail: isps-ubu@samarco.com

Harbor Master office (Brazilian Navy)

Telephone: +55 27 2124-6500

General Call: VHF Channel 16

Site: www.cpes.mar.mil.br



Pilotage office

Telephone: +55 27 3200-3898

General Call: VHF Channel 16 / 74

E-mail access: http://www.praticagem.org.br/faleconosco.asp

Public telephone, Post Office & fax services

Not available.

Medical assistance

Available at Guarapari City, located 15 km north from Ponta Ubu Terminal.

7. FINAL REQUIREMENTS & CONSIDERATIONS

Oil

The supply (and removal) of oily material shall be made by means of sealed drums. Pumping oil or oily waste is only allowed in the terminal in compliance with a series of additional and mitigating requirements in case of an accident and previously agreed with the terminal at least 48 hours in advance.

Diving

It shall always be monitored by Samarco personnel and shall be requested at least 48 hours in advance.

Waste removal

Shall only be carried out through the secondary entrance gate, even if it is transported by small vehicles, and only during day shift, with weighing being performed both when accessing and leaving Samarco and further issuing of the waste final disposal confirmation within 48 working hours, at the most.

Cleaning anchor chain and external hull marine growth and painting

It is not allowed in the area under Samarco's responsibility.

Cleaning hold comings and hatches, decks and adjoining areas

Cleaning with compressed air jet spreads particulate matters that contribute to the pollution of surrounding waters and beaches. Therefore, it is not allowed until the ship has passed by the buoys double number 1 and 2.

Repairs Onboard



Repairs that pose risk to safety, as hot work and others, shall be previously agreed with the terminal. Works that may partially or completely impair the ship's operational capacity also require previous written authorization, where the ship will assume responsibility for all costs directly or indirectly related to the repair.

Movement of the Crew

Members of the crew and other people moving around must wear shoes, pants and shirts and must be aware of the conveyor belts risk.

Simulation Drills

Simulation drills that may interfere with the terminal routine, including such as life boats, boats, external firefighting, etc shall be previously discussed. Terminal simulation drills shall be previously informed to Captains of ships that have been moored and/or anchored, as relevant.

Berthing and unberthing

For Berthing and Unberthing maneuvers, azimuth drive tugs must be used according to the use of tug table. In order to ensuring the safety of the berthed vessel she should be full time supported at least by one tug (minimum bollard pull 40 ton)

Wire ropes during mooring

The terminal shall be previously informed about ships that use wire ropes during mooring. Bollards SWL is 150 ton and quick release hooks is 100 ton. The mooring arrangements must be suitable with those values.

Ship Safety and Environment Inspection (LVS)

All ships located at Ponta Ubu are subject to inspection to be carried out by the port team, and might have their ballast water sampled for analysis.

Ballasting

Removal of water in good condition and in compliance with Resolution A868 and the Brazilian Maritime Authority Standard (NORMAM-20) is a procedure included in the terminal routine. However, water cannot be dumped on the guay or on port structures even when clear.

Kit SOPEP

For possible environmental incidents the ship shall be adequately and proportionately equipped with SOPEP Kit. The use of dispersants is not allowed without previous authorization of the competent environmental authorities.

ISPS

Pre-operational forms related to ISPS and the crew list shall be issued within four days before ETA. At the end of loading, Declaration of Acknowledge must be returned to foreman filled up and signed.

Weather Restrictions

Concerning the safety conditions for berthing and/or leaving dock all of shifts will happen after a previous analysis of wind and sea among others. But, in advance, we can declare that no berthing will be booked whenever wind blows above 23 m/s, waves higher than 2.5m and/or



if the visibility is shorter than 800 m. However, very special situations can be analyzed by pilot and terminal and approved by consensus.

Waiting Vessels

There are two independent berths. Vessels queue is understood regarding the ship's particulars and berth restrictions. Hence, First-Come-First-Served (FCFS) principle is applied as much as possible, but always concerning the words above mentioned. The observation of this instruction summary does not exempt the ship from her responsibilities, and the list of recommendations herein does not include all legal practices and requirements or those established by the terminal. Additional information should be taken with the named ship's agent.

Masters are required to attach a copy of following documents upon returning of the present one:

- . Ballast Exchange Water Report (iron/ore vessels);
- . SOC Statement of Compliance (Annex 1);
- . Loading Plan/Sequence (when/if available);
- . Ports of Call List (last 10 ports);
- . Complete Ship's Particulars;
- . Crew List.

The compliance of above requirements, procedures and guidance are essential to avoid accidents, incidents, pollution, potential risks of death, human body injuries, loss of time and delay to port operations;

It is expected that all Masters besides to comply with all relevant International Conventions in force, to also follow the good sense and good marine practice as applicable and possible;

The use of this "Port Regulation" does not relieve the Master and his crew from their responsibilities and commitment with legal requirements and good practices;

For any other matter not treated herein, Masters may consult Foreman on duty or other members of the Port Administration, through their Agents as necessary;

This document issued by The Ponta Ubu Port Administration is given in good faith without prejudice for further right of defense;

Masters are required to make a short signature in all pages above besides the full signature of this last one.

Anchieta, ES, Brazil, October 21st, 2020.

By Ponta Ubu Port Administration



I, as Shipmaster, hereby state that all possible diligences, efforts and measures will be exercised on behalf of my Principals (Owners, Charterers, Managers and/or Operators), holders of the below mentioned vessel in order to fully comply with all above requirements and guidance of the present "Ponta Ubu Terminal Port Regulation".

Acknowledged by,
Master's Name:
Ship's Stamp, date/time and Master Signature
STATEMENT OF COMPLIANCE
From: (name of ship) IMO no.: To: Ponta Ubu Terminal
I, _ (name of Master), Master of the above mentioned vessel, hereby declare that the ship is covered with flag state statutory and class certificates in full term condition without outstanding items, and assure a good seaworthiness, adequateness, performance and safety operational conditions related to ship when operating at the Ponta Ubu Terminal. This assurance covers the main and auxiliaries engines, cargo holds, hatches (including opening and closing) and other necessary fittings in the cargo space, ballast system, deck gears, oi spill control systems including SOPEP, crew training, pumps, pipes, valves and also that coverage applies to any loss, damage and delay directly a/or indirectly related with any operational deficiency that may arise from the ship, and she is able to comply with the regular port conditions and the deballasting operations to occur simultaneously with loading operations according to the following:
Ponta Ubu Terminal at berth: () East side / () West side Maximum loading rate: 12,000 t/h Average loading rate: 10,000 t/h Maximum Ship´s Air Draft: 20.00 m
Ship loader will change from one hatch to another with maximum 20m air draft. Is there any deck obstruction between the first and last hatch? If yes, please attach photos. () NO () YES



Vessel is held fully accountable for the information provided and will be liable for any delays and costs arising from misinformation provided.

List of certificates:

CERTIFICATES ISSUE EXPIRY

SHIP REGISTER CERTIFICATE

CARGO SHIP SAFETY CONSTRUCTION CERTIFICATE

INTERNATIONAL LOAD LINE CERTIFICATE

IOPP / MARPOL CERTIFICATE

INTERNATIONAL SAFETY MANAGEMENT - (ISM)

P & I CLUB CERTIFICATE OF ENTRY

INTERNATIONAL SHIP SECURITY CERTIFICATE (ISSC)

DOCUMENT OF COMPLIANCE

(*) Any certificate in condition other than in full term status gives the right to accept or reject the ship's nomination submitted to terminal's consideration.

The above statement is given in true words, good faith and free-will and issued by Owners and/or Shipmaster in the ship's interest

Date:

Signed by: (name / rank / stamp)

ANNEX LIST:

- 1. Formal Authorization for Repairs
- 2. Simulation Drill Formal Authorization
- 3. Safety and Environment Check List (tankers)
- 4. Safety and Environment Chart
- 5. Declaration of Acknowledge
- 6. Samarco Loading Plan Form



FORMAL AUTHORIZATION FOR REPAIRS

Ponta Ubu,, 20, YEAR
The Master of MV " "(vessel's name) hereby declares his intentions to proceed with maintenance repairs which will require the immobilization of the vessel for hours which is less than half time between the end of the repairs and her ETD (Estimated Time of Departure).
Therefore, in accordance with the Terminal rules, it means that it will happen under owner's and captain's supervision and in accordance with maritime law and rules and whatsoever costs that arise, directly or indirectly linked with that labor and/or any eventual delay will be under ship's account.
Agree
Capt
NAME OF CAPTAIN
Vessel's Stamp:



SIMULATION DRILL FORMAL AUTHORIZATION

Ponta Ubu,, 20, YEAR
The Master of the M/V "" hereby declares his intentions to carry out the drill (drop the rescue boat, firefighting, etc.)
However, in accordance with the Terminal rules, whatever happens with the life rafts, rescue boats, crew or any other device will be under owner's and master's supervision and in accordance with maritime law and rules. Thus, Master agrees that whatsoever costs that arise, directly or indirectly linked with that drill and/or any eventual delay will be under ship's account.
Agree
Capt
Vessel´s Stamp:





LISTA DE VERIFICAÇÃO E SEGURANÇA(LVS) Safety and Environment Check List

SHIP:	Date:	
Summer DWT:	IMO Nr:	
DESCRIÇÃO DOS ITENS	status	OBSERVAÇÕES
ITEMS DESCRIPTION		REMARKS
01- A amarração é adequada às condições locais de maré, corrente, ventos, tráfego e embarcações atracadas a contrabordo ? 01- Are mooring arrangements adequate for all local effects of tide, stream, weather,		
traffic and craft alongside ?		
02- Os cabos de reboque de emergência estão devidamente posicionados ? 02- Are the emergency towing wires correctly positioned ?		
03- Existem meios seguros de acesso entre navio e terminal ? 03- Is there safe access between ship and		
wharf?		
04 - Em caso de emergência, o navio está pronto a navegar por seus próprios meios? E, em caso negativo, foi feita a solicitação prévia de reparo ao terminal (via agência) ? 04 - In an emergency, is the ship able to		
leave the berth soon as required ? Otherwise,		
has the terminal been previously informed? 05- Existe efetivo serviço de vigilância no convés e adequada supervisão a bordo e no terminal? 05 - Is there an effective deck watch in attendance on board and an adequate supervision either in terminal or on ship?		
06- Foram estabelecidos os procedimentos para as operações envolvendo carga, lastro e abastecimento? 06- Have the procedures for cargo, bunker and ballast handling been agreed?		
07- Todos os riscos com substâncias tóxicas contidas na carga estão identificados e compreendidos (Fichas MSDS)? 07- Have the hazards associated with toxic substances in the cargo handled been identificated and understood (Data Sheet)?		
08- Os mangotes de carga e combustível es-		
tão em boas condições, adequadamente su-		



portados e adequados ao serviço ?	
08- Are cargo and bunker hoses in good	
condition and properly rigged and appropriate	
for the service intended ?	
09- Os embornais e bandejas coletoras es-	
tão em boas condições, adequadamente bu-	
jonadas a bordo e em terra ?	
09- Are all the scuppers and drip trays	
effectively plugged on board and ashore?	
10- As conexões de carga e combustíveis	
que não estão em uso, foram devidamente	
fechadas com flanges cegos e totalmente	
aparafusadas ?	
10-Are unused cargo and bunker connections	
properly blanked and fully screwed?	
11- O navio possui "Plano de gerenciamento	
de Lastro" apropriado e o está executando?	
11- Has the ship an appropriate "Ballast	
Management Plan"?Has it been obeyed?	
12- As condições operacionais das válvulas	
de vácuo-pressão e ou suspiros de alta velo-	
cidade são checados por check list apro-	
priado?	
12-Have the operation conditions & instalation	
of vacuum and pressure valves and / or high	
velocity vents been checked by a proper	
checklist?	
13- As lanternas elétricas portáteis são do	
tipo aprovado?	
13- Are hand torches of an approved type?	
14- Os transceptores portáteis de VHF/uhf	
são do tipo aprovado?	
14 Are portable vhf / uhf transceivers of an	
approved type?	
15- Todas as portas externas e demais co-	
municações estão fechadas ?	
15- Are all external doors and exits closed?	
16- As entradas de ar para equipamentos de	
ar condicionado que possam permitir entrada	
de vapores de carga estão fechadas?	
, ,	
16- Are the air conditioning intakes which may permit the entry of cargo vapours closed?	
17- As restrições de fumo e chamas abertas	+ +
estão sendo observadas ?	
17- Are smoking and naked lights regulations	
being observed ?	
18- Existe pessoal suficiente a bordo e no	+ +
terminal para enfrentar uma emergência ?	
18- Are there enough crew on board and	
staff on terminal to face an emergency?	
19- Existem meios adequados de isolamento	
elétrico na conexão navio / terminal ?	
19-Are there adequate insulating means in the	
13-Are mere avequate mountainy means in the	I I



shin/share connection 2	
ship/shore connection ?	
20- Foram tomadas as medidas adequadas	
a garantir a ventilação da casa de bombas ?	
20- Have measures been taken to ensure	
satisfactory pumproom ventilation ?	
21-Os planos de emergência do navio p/ com-	
bate incêndio estão dispostos externamente?	
21- Is the fire control plan located externally?	
22- O sistema de gás inerte está completa -	
mente operacional?	
22- Is the inert gas system fully operational	
and in good working order?	
23- Oxímetros, explosímetros e "tank escope"	
estão calibrados e em boa condição de uso?	
23- Have the portable oxygem analysers,	
explosimeter and tank scope been calibrated	
and are they working properly?	
24- Todos os tanques estão com suas	
atmosferas com pressão positiva e teor de	
O2 menor ou igual a 8 %?	
24 -ls the pressure positive in all cargo tanks	
with an oxygen content of 8 % or less per volume?	
25- Todas as válvulas individuais de gás iner-	
te dos tanques (quando equipado) estão cor-	
retamente alinhadas e travadas ? 25- Are all tanks individual Inert Gas valves	
corretly set and locked?	
26- As pessoas envolvidas na operação têm	
conhecimento que, caso haja falha da planta	
de GI, as operações devem ser interrompidas	
e o terminal avisado ?	
26 - Are all the people in charge of cargo	
operations aware that in case of failure of the	
gas inert plant, operations should be stopped	
and the terminal advised ?	
27- O dispositivo de parada de emergência	
das bombas de carga está operacional?	
27- Is the cargo pumps emergency shut down	
system working appropriatly?	
28- O livro de registro de carga está com os	
registros atualizados e coerentes ?	
28- Is the cargo record book up to date, and	
coherent?.	
29- O lixo de bordo está corretamente acon-	
dicionado e pronto para ser retirado p/ empre-	
	i l
sa credenciada ?	
sa credenciada ? 29- Is the garbage corretly conditioned and	
sa credenciada ? 29- Is the garbage corretly conditioned and ready to be taken to shore? Are the receivers	
sa credenciada ? 29- Is the garbage corretly conditioned and	
sa credenciada ? 29- Is the garbage corretly conditioned and ready to be taken to shore? Are the receivers	



30- Is the garbage record book up to date and coherent ?	
31- O navio está com "kit SOPEP"adequado e disponível ? 31- Is there a "SOPEP kit" available and also adequate?	
32- É boa a condição geral do convés e da	
superestrutura?	
32- Are the decks and superstructure in good	
condition ?	
33- O livro de registro de óleo está atualizado	
e coerentemente preenchido, de acordo com	
as informações contidas no IOPP ?	
33- Is the Oil Record Book up to date and	
perfectly coherent (IOPP)?	
34- A "dala" apresenta boas condições de	
conservação , não representando risco po-	
tencial ao meio ambiente ?	
34- Is the bilge hold space in good condition	
meaning no risk to the environment?	
35- O separador de água e óleo está com a	
descarga para o costado fechada e possui	
alarme de 15 ppm visual e sonoro operante?	
35 Is the oily water separator discharge valve	
closed and the 15 ppm alarm working as	
intended (light and sound) ?	
36- A unidade de tratamento sanitário está	
funcionando normalmente ?	
36- Is the sewage treatment unit working	
appropriatly ?	
37- A estado geral da praça-de-máquinas é bom?	
37- Is the engine room in good general condition?	
38- Os detectores de gases inflamáveis da	
casa de bombas estão operando conforme	
previsto no SOLAS ?	
38- Are the gas detectors in the cargo pumproom	
working in acordance with SOLAS ?	
39-Os postos de incêndio estão em condições de uso?	
39- Are the fire stations ready for use ?	
40-Os oficiais de bordo podem identificar pes-	
soa designada p/ emergência ambiental ?	
40- Can senior ship officers identify the	
Designated Person ?	

FOR SHIP	FOR TERM	/INAL
NAME	NAME	
FUNÇÃO/RANK	FUNÇÃO/RANK	
SIGNATURE/STAMP	SIGNATURE /STAMP	



Anchieta (Ponta Ubu),,,	

From: Ponta Ubu Maritime Terminal

To: Master of M/V

Ref.: Safety and Environment Checklist

Welcome to Ponta Ubu Maritime Terminal. Below you will find important information that will make your stay more safer. Samarco Mineração S.A. strongly believes in a partnership work between Terminal and the berthed vessels. It also believes in a harmonious coexistence between port activities and preservation of the local environment.

- 1- Channel VHF 16 should be used for communication between vessel and Terminal.
- 2- If communication difficulties are found, the vessel can use two long followed by two short blasts to indicate emergency condition. This will cause the loading operations to stop, among others.
- 3- At the sentry office there radio and telephone to be used in case of emergency, as well as to get urgent medical help, which is available 24 x 7.
- 4- There is a permanently pressurized fire system below the pier. Six hydrants, whose position is indicated by red lids, are alternately distributed between East and West berths.
- 5- One ASD 45BP tugboat is available full-time at the Terminal. If necessary, ask to foreman.
- 6- For bunkering operations, additional measures should be taken. The vessel or its Agent should ask for previous authorization at least 24 hours before the operations, by e-mail "porto.adm@samarco.com".
- 7- Internal operations involving bunker, diesel oil and/or oily residues (such as pumping from one tank to another) can only be made with Terminal's previous authorization, and always during daytime.
- 8- In order to safety of life, ship's supplies should be taken on board by means of provisions cranes, not by the gangway or access plank.
- 9- As part of our Safety Policy and control of alcoholic beverages, Samarco kindly asks that crewmembers clearly showing signs of alcohol consumption should only go on board if accompanied by the Duty Officer on deck.
- 10- A surveyor from the Terminal are routinely designated to make a safety and environment inspection on board, always accompanied by Duty Officer. The aim of this action is to ask the Master and his crewmembers to become our partners in keeping the local environment safe and clean.
- 11- Vessel must has an appropriate "Ballast Management Plan". Samarco fully cooperates with Global Ballast program, and samples of ballast water are taken with Master's permission.



- 12- Hull maintenance like cleaning or painting is not allowed during vessel's stay in port, except mandatory hull markings.
- 13- Welding, propeller repairs and the lowering of lifeboats as drills should be previously arranged with the Terminal.
- 14- All kinds of repairs that could eventually stop the vessel from leaving the berth at any time are not allowed. Exceptions, however, will be analysed separately. All applications should be addressed to the Terminal's Manager.
- 15- Walking on the pier is only allowed between vessel and the sentry office with appropriate clothes, like sleeved shirts, trousers and protective footwear.
- 16- In case of oil/oily residue spilling overboard and into the sea, Samarco will immediately launch its Emergency Plan.
- 17- All decks, superstructure and Engine Room must be kept in good condition.
- 18- The Oil Record Book must be up to date and perfectly coherent.
- 19- The bilge hold space must be in good condition meaning no risk to the environment.
- 20- Vessel's mooring arrangements must be adequated for all local effects of tide, stream, weather, traffic and craft alongside.
- 21- All the scuppers and drip trays must be effectively plugged.
- 22- All unused cargo and bunker connections must be properly blanked and fully screwed.
- 23- An International Shore Fire Connection must be available at main deck.
- 24- An adequate "SOPEP kit" must be available and stand-by all time.
- 25- According to the Port Authority's rule, it is not allowed to keep a ladder lowered by the sea edge.
- 26- Sulfur content (SOx ppm) in the fuel used by the main engine: ______.

27- Intended departure Metacentric Height (GM), according to cargo plan: _____m.

Any apparent risk to environment or to person/equipment should be immediately informed.

Thank you very much for your cooperation. We wish you and your crewmembers a very nice stay in our Terminal.

onta Ubu Maritime Terminal	
eceived/Acknowledged by M/V	
Ship Stamp:	
gn / Rank	



ANNEX 5 SAMARCO MINERAÇÃO S/A

DECLARAÇÃO DE CIÊNCIA – (DECLARATION OF ACKNOWLEDGE)

DECLARO que tomei ciência da obrigatoriedade de registrar, caso ocorram, os danos ou atos ilícitos contra esta embarcação, tripulantes ou passageiros e seus pertences e/ou carga, durante a permanência e a interface da embarcação com a instalação portuária.

I declare that i've became aware of the obligation to record, in the event of damage or illegal acts against this

ship, crew or passengers and their belongings a	nnd/or cargo, during the stay and ship/port interface.
EMBARCAÇÃO - SHIP	T
Nome do Navio - Ship's name	
Porto de Registro - Port of register	
Número na IMO - IMO number	
Comandante ou Oficial de Proteção da Embarcação: (Commanding Officer or Ship Security Officer	
Identificação - Identification	
INSTALAÇÃO PORTUÁRIA - PORT FACII	ITY
Razão Social/Nome - (Name of the port facility)	SAMARCO MINERAÇÃO S/A
Endereço - Adress	Rodovia Es 060, km 14,4 – s/nº - Ponta Ubu - 29230 – Anchieta – ES - Brasil
Número na IMO - IMO number	BRVIX-0004
Número da declaração de Cumprimento – (Number of the Statement of Compliance)	033/2004
Situação atual da declaração de Cumprimento - (Current situation of the Statement of Compliance)	() Vigente () Suspensa () Cassada (X) Effective () Suspended () Canceled
assinar a presente DECLARAÇÃO impõe ao Su fato formalmente neste formulário e adote as pro ATTENTION: The Commanding	o Comandante ou do Oficial de Proteção da embarcação, em pervisor de Segurança da Instalação Portuária que consigne d ovidências previstas na presente Resolução. Officer's or Ship Security Officer's refusal to sign this ity Officer to formally record the fact in this form and to take the
OBSERVAÇÕES (Remarks):	
Local e data- Local and Date:	
Comandante ou Oficial de Proteção da Embarca (Commanding Officer or Ship Security Officer)	ação:
Supervisor de Segurança da Instalação Portuári (PortFacility Security Officer)	ia:



LOADING SEQUENCY (ONE LOADER) VESSEL: DEBALLASTING PUMPING RATE: DISCHARGE PORT: Type Type Auantity Auantity
[AZ] DS